


Front end cylinder with outer cover

49-102 ton



mounting dimension 323					mm + 20 mm min pull out					l stroke	:	5110 mm	max pressure	220 bar	
model: PFC1590 5110 174 4 code: 4215901744001W									weig	ght: 39	1 kg	HS Penta			
extension	1	2	3	4	-	-	-	-	-			number of	stages: 4		
diameter [mm]	174	154	135	116											
stroke [mm]	1331	1336	1345	1098								total: 5110 ı	mm		
thrust [kN]	524	410	315	232								max thrust	admitted: 265 kN		
oil [dm³]	31.6	24.9	19.3	14.3								total: 90.1 d	m3		

TECHNICAL NOTES AND SPECIFICATIONS

- The normal application of telescopic cylinder is to lift up tipping bodies, loaded with different materials, and consequently discharge this material whilst the cylinder is extended
- The body weight plus the max payload are the max tipping weight that can be raised by the cylinder. This value, calculated at the max pressure, is a rough indication of the tipping power of the cylinder and must be used as a first criteria for the selection of the cylinder. The real tipping mass can only be calculated by the design engineer of the dump truck, and must take into account the geometry of the dump body and operating conditions. Never exceed the maximum thrust.
- Never exceed maximum pressure.
- Never exceed maximum pressure.

 The cylinder has been designed for loads along the longitudinal axis: the cylinder is a lifting device only and may not be used as structural member or be subject to side load. The ordinary use of telescopic cylinder does not require any coating as the telescopic stages are exposed to atmospheric agents only during the tip-up operation. Therefore telescopic cylinders will be supplied without any coating in absence of any specific requirements.

 H.S.PENTA warranty does not apply to any kind of corrosion of coated or non-coated parts. See terms of warranty.

 Maximum extension speed less than 0.2 m/s.

 Hydraulic oil temperature admitted between 40°C and +10°C.

- Hydraulic oil temperature admitted between -40°C and +100°C.
- In case the cylinders must be stored, do not remove the package. Store them in a dry place, not exposed to rain. Do not store the cylinders for more than 6 (six) months. Further specifications see mounting instructions, hydraulic oil specification sheet, user & maintenance manual.

REMARKS	[1994.04.28] [1994.04.28]	REVISIONS	
Last stage Ø116 chromed (Elem. t	erm. Ø116 cromato)	2008.12.16 - Aggiornamento dati	01
			02
			03
		Hada Francis Manager	04